

PORTO COLLECTION INSTALL INSTRUCTIONS

BY SIMPLY FOLLOWING THESE STEP-BY-STEP INSTRUCTIONS, YOU WILL SOON BE ENJOYING YOUR NEW DRAPERY HARDWARE.

Getting Started:

Please read through all instructions carefully before you begin installation.

Unpack all materials making sure all components are included:

- Pole
- Drapery rings
- Mounting brackets with Allen key
- Finials

Please note that your brackets must be securely attached to the mounting surface. If your screws do not hit wood studs you'll have to use a different fastener, which can be found at any local hardware store.

Tools You Will Need:

- Drill with a 1/8" bit and a Phillips bit
- Phillips screwdriver
- Metal tape measure
- Hacksaw (optional)

Installing Your Porto Wrought Iron Drapery Hardware:

You are now ready to install your hardware.

1. Measure

Measure the area you are covering and cut down pole if needed with hacksaw. Poles are pre-cut to your specifications.

2. Mark

Mark the height you would like the top of drapery pole to be installed. Note: The top of the drapery will hang down approx. 2" from the top of the pole.

3. Mount

Place the top of the bracket 1" above marked height. Drill in screws through the pre-drilled holes on the base of the bracket for a secure mount. Repeat this process for all other brackets.

4. Attach Rings and Pole

Slide rings onto pole. You may want to leave one ring on the outside of each of the end brackets. Set pole on brackets. Tighten screw on the front of the bracket to fasten pole in place.



5. Attach Finials

Attach finials to both ends of the pole.