

T-RAIL COLLECTION INSTALL INSTRUCTIONS

BY SIMPLY FOLLOWING THESE STEP-BY-STEP INSTRUCTIONS, YOU WILL SOON BE ENJOYING YOUR NEW DRAPERY HARDWARE.

Getting Started:

Please read through all instructions carefully before you begin installation.

Unpack all materials making sure all components are included:

- Rail
- Carriers
- Bracket with Allen key

Please note that your brackets must be securely attached to the mounting surface. If your screws do not hit wood studs you'll have to use a different fastener, which can be found at any local hardware store.

Tools You Will Need:

- Drill with a 1/8" bit and a Phillips bit
- Phillips screwdriver
- Metal tape measure

Installing Your T-Rail System:

You are now ready to install your drapery hardware.

1. Measure

Rails are pre-cut to your specified size.

2. Mark

Mark the height you would like the top of drapery rail to be installed. Note: The top of drapery will hang down approx. 1 1/8" from top of rail to top of drapery.

3. Mount

Attach your back plates to your desired area. Drill screws through holes for a secure mount. Repeat this process for all other brackets.

4. Attach Bracket

- Place decorative faceplate over the back plate.
- Screw the bracket attachment shaft onto the threaded part of the back plate.
- Place your bracket unit onto the bracket attachment shaft.
- Screw bracket set screw (with included Allen key) into the hole on the top of the bracket unit closest to the wall until it is tight.

5. Insert Rail

Insert rail into slot on socket and tighten set screw to hold in place.

