

PANEL SYSTEM (CORD DRAW) INSTALL INSTRUCTIONS

BY SIMPLY FOLLOWING THESE STEP-BY-STEP INSTRUCTIONS, YOU WILL SOON BE ENJOYING YOUR NEW DRAPERY HARDWARE.

Cord Draw

Getting Started:

Please read through all instructions carefully before you begin installation.

Unpack all materials making sure all components are included:

- Assembled Panel System track
- Brackets
- Tension Pulley
- Counterweight, optional

Please note that your brackets must be securely attached to the mounting surface. If your screws do not hit wood studs you'll have to use a different fastener, which can be found at any local hardware store.

Tools You Will Need:

- Drill with a 1/8" bit and a Phillips bit
- Phillips screwdriver
- Metal tape measure

Installing Your Panel System (Cord Draw):

You are now ready to install your panel system hardware.

Wall Mount:

- 1. Measure**
Rails are pre-cut to your specified size.
- 2. Mark**
Mark the height you would like the top of the panel rail to be installed. Note: The top of the panel will hang down approx. 1 1/8" from top of rail to top of the panel.
- 3. Attach Bracket**
Attach your brackets to your desired area. Drill screws through holes for a secure mount. Repeat this process for all other brackets.
- 4. Attach Track**
Insert track onto bracket and turn swivel to lock in place.
- 5. Attach Tension Pulley**
First attach the backplate to the wall on the control/chain side of your Panel System. Then wrap cord around pulley and adjust so that chain is tight. Snap cover in place.
- 6. Optional Counterweight**
Slide counterweight into bottom hem pocket.

Ceiling Mount:

- 1. Measure**
Rails are pre-cut to your specified size.
- 2. Attach Bracket**
Attach bracket to ceiling by first pre-drilling holes for screw diameter when mounting into a ceiling stud. Otherwise, pre-drill and install anchors first before fastening with screws. Tracks hold 6 lbs/ft. Support brackets occur every 4 feet.
- 3. Attach Track**
Insert track into bracket applying pressure until it "clicks" into place.
- 4. Attach Tension Pulley**
First attach the backplate to the wall on the control/chain side of your Panel System. Then wrap cord around pulley and adjust so that chain is tight. Snap cover in place.
- 5. Optional Counterweight**
Slide counterweight into bottom hem pocket.

PANEL SYSTEM (BATON DRAW) INSTALL INSTRUCTIONS

BY SIMPLY FOLLOWING THESE STEP-BY-STEP INSTRUCTIONS, YOU WILL SOON BE ENJOYING YOUR NEW DRAPERY HARDWARE.

Baton Draw

Getting Started:

Please read through all instructions carefully before you begin installation.

Unpack all materials making sure all components are included:

- Assembled Panel System track
- Brackets
- Baton
- Counterweight, optional

Please note that your brackets must be securely attached to the mounting surface. If your screws do not hit wood studs you'll have to use a different fastener, which can be found at any local hardware store.

Tools You Will Need:

- Drill with a 1/8" bit and a Phillips bit
- Phillips screwdriver
- Metal tape measure

Installing Your Panel System (Baton Draw):

You are now ready to install your panel system hardware.

Wall Mount:

- 1. Measure**
Rails are pre-cut to your specified size.
- 2. Mark**
Mark the height you would like the top of the panel rail to be installed. Note: The top of the panel will hang down approx. 1 1/8" from top of rail to top of the panel.
- 3. Attach Bracket**
Attach your brackets to your desired area. Drill screws through holes for a secure mount. Repeat this process for all other brackets.
- 4. Attach Track**
Insert track onto bracket and turn swivel to lock in place.
- 5. Attach Baton**
Attach baton to the baton adaptor.
- 6. Optional Counterweight**
Slide counterweight into bottom hem pocket.

Ceiling Mount:

- 1. Measure**
Rails are pre-cut to your specified size.
- 2. Attach Bracket**
Attach bracket to ceiling by first pre-drilling holes for screw diameter when mounting into a ceiling stud. Otherwise, pre-drill and install anchors first before fastening with screws. Tracks hold 6 lbs/ft. Support brackets occur every 4 feet.
- 3. Attach Track**
Insert track into bracket applying pressure until it "clicks" into place.
- 5. Attach Baton**
Attach baton to the baton adaptor.
- 6. Optional Counterweight**
Slide counterweight into bottom hem pocket.