

CM INSTALL INSTRUCTIONS

BY SIMPLY FOLLOWING THESE STEP-BY-STEP INSTRUCTIONS, YOU WILL SOON BE ENJOYING YOUR NEW DRAPERY HARDWARE.

Getting Started:

Please read through all instructions carefully before you begin.

Unpack all materials making sure all components are included:

- Track(s)
- Master carrier(s) & carriers (pre-installed within track)

Tools You Will Need:

- Drill with a 1/8" bit and a Phillips bit
- Phillips screwdriver
- Metal tape measure
- Hack saw (optional)

CM Track Ceiling Mount Instructions:

Installing Your Drapery Track:

You are now ready to install your Forest Drapery Track System.

1. Mark

Hold your track in position on the ceiling and mark the screw hole spots where you will pre drill mounting holes.

2. Drill

Pre-drill and insert anchors as needed for secure installation.

3. Attach Track

Align track with pre-drilled holes and fasten with screws.

OPTIONAL: Drill directly through the flange if necessary for a secure installation.

